

Fuel Tank Access Cover Drill Guide
PN#: 24-120

Great time saver for drilling the holes for both the access cover and the retaining ring for the main fuel tanks. Use it to also drill the holes in the tank. Avoids the time-consuming layout of the holes and the inevitable mis-drilling of the holes.

The hole pattern is the standard pattern for a typical capacitance fuel sender. Also has the hole pattern for the nut plates for those who do not own a nut plate jig. Use the same guide for both covers. Recommend the use of a centering drill when drilling the holes to avoid damage to the drill guide.

